


Molded Directions




HIROSE HR10A-10LP-12S
 Female Connectors

**CCD CAMERA CONNECTOR
 Jack Male Pin**


The cable will come out at the pin No(3).

(Left Side)




(Up Side)

The cable will come out at the pinNo(1,9).



The cable will come out at the pin No(7).

(Right Side)



16.4 (0.1)mm

9.2 (0.1)mm

The cable will come out at the pin No(5).

(Down Side)

